


HU Adjustable Rest

Thank you for purchasing our product, please read the following instructions carefully before using our product.



Parts

- | | | |
|--------------------------|------|------|
| ① Rest Pin Sliding Plate | | |
| ② Rest Pin | | |
| ③ Base Plate | | |
| ④ Screw | | |
| ⑤ Magnet | | |
| ⑥ Lead | Blue | 1.05 |
| | Red | 1.10 |

Tuning

The Vertical Position Adjustment

Loosen ④ slightly in order to slide the rest pin vertically.
The movable range is 2.5 mm.

The Horizontal Angle Adjustment

This rest is not designed to adjust the vertical movement.

*** Caution *** Do not bend the pin to adjust. It will break the rest pin.

Cut the rest pin to adjust the length.



Notes

- * Regarding of the size of the rest pin, the larger the number is, the bigger the diameter of the pin. The diameter of the pin is represented by color on the lead: 1.05 mm by blue, 1.10 mm by red.
- * If you wish to use a Magnetic Rest for arrows of different diameters and/or weights, we recommend using our **Free Tuning Rest**.

Please keep away the magnet from credit cards, floppy disks or any other magnetic storage. It causes to damage or loss data.